

MAGNUM & MCS-8 Micro Controller Systems



Simplified Description and Troubleshooting

Magnum and MCS-8 Micro Controller Systems
Simplified Description and Troubleshooting
Revision 2.03

The MCS Commitment

Our commitment is to provide practical solutions for the industry's needs and to be both a leader and a partner in the effective use of microprocessor controls.

Micro Control Systems, Inc.
5580 Enterprise Parkway
Fort Myers, Florida 33905
USA
Phone: (239) 694-0089
Fax: (239) 694-0031
www.mcscontrols.com

Information contained in this manual has been prepared by Micro Control Systems, Inc. and is company confidential and copyright © protected 2009. Copying or distributing this document is prohibited unless expressly approved by MCS.

Table of Contents

Section 1 – Magnum Micro Controller Systems

Troubleshooting General Dead Board Symptoms.....	6
Troubleshooting Sensor Input Problems	7
Troubleshooting Relay Output Problems.....	8
Troubleshooting Lost I/O Communication Problems	9

Appendix G – Entering Authorization Codes to Log In and Out of a Magnum.....	10
Appendix H – Manually Turning On and Off a Magnum, MCS-I/O or RO8 Relay Output	12
Appendix I – Determining and Changing the Network Address of a Magnum	14
Appendix J – Analog Sensor Input Reference Table	16
Appendix K – Resolving MCS-I/O and RO8 Snubber Network Leakage Issues.....	17

Table of Contents


Section 2 – MCS-8 Micro Controller Systems

Troubleshooting General Dead Board Symptoms.....	19
Troubleshooting Sensor Input Problems	20
Troubleshooting Relay Output Problems.....	21
Troubleshooting Lost I/O Communication Problems	22
Troubleshooting LCD Problems.....	23
Troubleshooting MCS-UPC Problems	24


Appendix A – Entering Authorization Codes to Log In and Out of a MCS-8.....	25
Appendix B – Manually Turning On and Off a MCS-8, I/O or RO8 Relay Output	26
Appendix C – Determining and Changing the Network Address of a MCS-8	27
Appendix D – Analog Sensor Input Reference Table	28
Appendix E – MCS-UPC Status LED Code Descriptions.....	29
Appendix F – Resolving MCS-8, I/O and RO8 Snubber Network Leakage Issues.....	30

Section 1

MAGNUM Micro Controller Systems





Magnum Micro Controller Systems
Troubleshooting General Dead Board Symptoms



Magnum Micro Controller Systems

Troubleshooting Sensor Input Problems





Magnum Micro Controller Systems

Troubleshooting Lost I/O Communication Problems

Appendix G

Entering Authorization Codes to Log In and Out of a Magnum

First, at the Main Menu use the arrow keys to navigate to **Passwords**:

```
09:56 Main Menu
-Status      -Setpoints
-Outputs     -Serv Tools
-Inputs      -Lckout RST
-Alarms      -Lckout ALM
-Graphs      -Passwords
Help
```

Next, press the Enter key. You will see the following:




```
09:56 Password
Enter Pin
----
Then Press '↵' Key
1 2 3
```

Now enter the proper four-digit authorization code. Each - is changed to a * as numbers are entered. After you have keyed in the numbers, press the Enter key.

```
09:56 Password
Enter Pin
****
Then Press '↵' Key
1 2 3
```

Appendix G (continued)

Entering Authorization Codes to Log In and Out of a Magnum

<p>The Magnum will tell you if it accepted your code and the level of authorization. For example, if you entered a valid factory authorization code you will see the following:</p>	 <p>09:56 Password Level - Factory Press 'MENU' Key 1 2 3</p>
<p>If you entered an invalid authorization code you will see the following:</p>	 <p>09:56 Password Level - VIEW ONLY Invalid Pin Press 'MENU' Key 1 2 3</p>
<p>Once you are logged in you can log out immediately by simply entering any invalid authorization code. If you are logged in and no keys are pressed for more than 15 minutes the Magnum will automatically log you out, warning you shortly before with how many seconds remaining as shown here:</p>	 <p>Press Any Key to Avoid Auth Log Out 60</p>



Appendix H

Manually Turning On and Off a Magnum, MCS-I/O or RO8 Relay Output

<p>Note: If a relay is in a Lockout state you cannot manually turn it on or off.</p> <p>First, after logging into the Magnum with your authorization code (see Appendix G), use the arrow keys to navigate to Outputs:</p>	<div style="border: 1px solid black; padding: 5px; margin: 5px;"> <pre> 09:56 Main Menu -Status -Setpoints -Outputs -Serv Tools -Inputs -Lckout RST -Alarms -Lckout ALM -Graphs -Passwords Help </pre> </div>
<p>Next, use the up and down arrow keys to highlight the relay you want to turn on or off:</p>	<div style="border: 1px solid black; padding: 5px; margin: 5px;"> <pre> 09:56 Outputs ◀▶ Relays Status M-1 COMP1-1 Off M-2 LOAD1-1 Off M-3 UNLOD1-1 Off M-4 LLS1-1 Off Anlog PG↑ PG↓ </pre> </div>
<p>Now press the Enter key. You should see something similar to the following:</p>	<div style="border: 1px solid black; padding: 5px; margin: 5px;"> <pre> 09:56 Outputs ◀▶ Relays Status M-1 COMP1-1 M-1 Manual AUTO M-1 Status M-4 LLS1-1 Off Anlog PG↑ PG↓ </pre> </div>

Appendix H (continued)

Manually Turning On and Off a Magnum, MCS-I/O or RO8 Relay Output

<p>Use the up and down arrow keys to cycle through the three modes for the relay output: AUTO, MANON or MANOFF Stop when you reach the one you want:</p>	
<p>Finally, press the Enter key to make the change. In our example the relay output is now manually turned on as shown here:</p> <p><i>Remember to return the relay output to AUTO mode when you are done!</i></p>	

Appendix I

Determining and Changing the Network Address of a Magnum

First, at the Main Menu use the arrow keys to navigate to **Serv Tools**:

```
09:56 Main Menu
-Status          -Setpoints
-Outputs         -Serv Tools
-Inputs          -Lckout RST
-Alarms          -Lckout ALM
-Graphs         -Passwords
Help
```

Next, press the Enter key. You will see the following:

```
09:56 Serv Tools
-RS-485 Network 1
-Ethernet Network
-System Info
-Time / Date
-Display
PG↑ PG↓
```

Use the up and down arrow keys to highlight **Address**:


```
09:56 RS-485 Setup
Protocol          MCS
Address          1
Baud Rate        19200

Back
```

Appendix I (continued)


Determining and Changing the Network Address of a Magnum

Now press the Enter key. You should see something similar to the following:




09:56 RS-485 Setup
Protocol MCS
Address 1
Ba 0
Back

Use the up and down arrow keys to select the Address number:



09:56 RS-485 Setup
Protocol MCS
Address 2
Ba 0
Back

Finally, press the Enter key to make the change. In our example the RS-485 network address has been changed from 1 to 2:



09:56 RS-485 Setup
Protocol MCS
Address 2
Ba 0
Change Made
Back

Appendix J

Analog Sensor Input Reference Table

To troubleshoot analog sensor input problems and determine where the problem is, simply remove the sensor input connector block of the input you want to test and plug in a MCS-SENSOR-TEST block. If you do not have a MCS-SENSOR-TEST block you can connect a 100K ohm 1% ¼ watt resistor between the +5 and S1 pins of the suspect sensor input on the board with the original sensor connector block removed.

After you have done this, compare the reading displayed by the Magnum with the table of the most common sensor types on the right. If the reading is close to what is found in the table for that particular sensor type you can safely assume that the board is functioning normally and that the problem lies with the sensor itself or the wiring from the sensor to the board.

Sensor Type	Reading
CT100	57.0A
CT250	143.0A
CT500	287.0A
HUMD	54.0%
T100	77.0F
Ti150A	75.0P
Ti200	100.0P
Ti500	250.0P
Ti667A	334.0P


Appendix K

Resolving MCS-I/O and RO8 Snubber Network Leakage Issues

Each relay output on a MCS-I/O and RO8 board is protected by the use of on-board snubber networks. These networks consist of a resistor and capacitor in series connected from the common side of each relay to the normally open and normally closed sides. Its purpose is to suppress or “snub” the electrical arc that is produced when relay contacts open and close. Electrical arcs can shorten the useful life of a relay and can also cause the electronics on the controller board to malfunction.


In some cases the use of these snubber networks can cause an outbound device, such as a relay, to stay on even when the controlling relay on the MCS-I/O or RO8 board is turned off. This can occur in situations where the outbound device requires very little ac current to keep it on once it is energized. Because snubber networks normally pass a small amount of current when the circuit it is protecting is switched off, enough current may pass through these networks to keep the outbound relay on, even though the controlling relay is turned off.

An easy solution to this problem is to rewire the relay output as shown in the diagram to the right. As you can see, wiring the circuit in this way causes the outbound device to have the same voltage potential on both sides when it is not energized.




Section 2

MCS-8 Micro Controller Systems




MCS-8 Micro Controller Systems

Troubleshooting General Dead Board Symptoms




MCS-8 Micro Controller Systems

Troubleshooting Sensor Input Problems




MCS-8 Micro Controller Systems

Troubleshooting Relay Output Problems




MCS-8 Micro Controller Systems

Troubleshooting Lost I/O Communication Problems



MCS-8 Micro Controller Systems

Troubleshooting LCD Problems



MCS-8 Micro Controller Systems

Troubleshooting MCS-UPC Problems

Appendix A

Entering Authorization Codes to Log In and Out of a MCS-8

<p>First, press the SERVICE DIAGNOSTICS key several times until the following screen appears:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>AUTHORIZATION ENTER CHG/OPTION</p> </div>
<p>Next, press the ENTER key. You will see the following screen:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>ENTER AUTH #XXXX THEN 'ENTER' KEY</p> </div>
<p>Now enter the proper four-digit authorization code. Each X is changed to a 0 as numbers are entered. After you have keyed in the numbers, press the ENTER key.</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>ENTER AUTH #0000 THEN 'ENTER' KEY</p> </div>
<p>The MCS-8 will tell you if it accepted your code and the level of authorization. For example, if you entered a valid factory authorization code you will see the following:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>AUTH= FACTORY SEL NEXT OPTION</p> </div>
<p>If you entered an invalid authorization code you will see the following:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>AUTH # INVALID SEL NEXT OPTION</p> </div>
<p>If no keys are pressed for more than 15 minutes the MCS-8 will automatically log you out. To log out immediately simply enter any invalid authorization code. You will then see the following:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>AUTH LOGGED OFF SEL NEXT OPTION</p> </div>

Appendix B

Manually Turning On and Off a MCS-8, I/O or RO8 Relay Output

<p>Note: If a relay is in a Lockout state you cannot manually turn it on or off.</p> <p>First, after logging into the MCS-8 with your authorization code (see Appendix A), press the MANUAL OVERRIDES key until the following screen appears:</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> RELAY OUTs MANAL ENTER CHG/OPTION </div>
<p>Next, press the ENTER key. You will see something similar to the following, depending on what the first relay output is used for and what state it is currently in:</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> COMP1 OFF ENTER CHG/OPTION </div>
<p>Now press the INCREASE (+) or DECREASE(-) key until you have reached the desired relay output. Once there, press the ENTER key. For example:</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> FAN 1 OFF ENTER CHG/OPTION </div>
<p style="text-align: center;">Press the ENTER key to go into the change mode:</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> FAN 1 AUTO ENTER OR +- </div>
<p style="text-align: center;">Press the INCREASE (+) or DECREASE (-) key to cycle through the three modes for the relay output: AUTO, MANON or MANOFF Stop when you reach the one you want:</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> FAN 1 MANON ENTER OR +- </div>
<p>Finally, press the ENTER key to make the change. In our example the relay output is now manually turned on as shown here:</p> <p>Remember to return the relay output to AUTO mode when you are done!</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> FAN 1 MANON CHG MADE/NXT-SEL </div>

Appendix C

Determining and Changing the Network Address of a MCS-8

<p>First, after logging into the MCS-8 with your authorization code (see Appendix A), press the SERVICE DIAGNOSTICS key until the following screen appears:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> UNIT INFORMATION ENTER CHG/OPTION </div>
<p>Next, press the ENTER key. You will see which version of software the MCS-8 is currently running and the configurator type. For example:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> SOFTWARE CFG CHL S08.23-B 6 </div>
<p>Now press the INCREASE (+) or DECREASE (-) key until the NETWORK ADDRESS screen appears. Here you will see what the network address of the MCS-8 currently is. For example:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> NETWORK ADDRESS MCS-8 ADDRESS 1 </div>
<p style="text-align: center;">Press the ENTER key to go into the change mode:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> NETWORK ADDRESS +- CHNG/ENTER 1 </div>
<p style="text-align: center;">Press the INCREASE (+) or DECREASE (-) key to cycle through addresses. Stop when you reach the one you want.</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> NETWORK ADDRESS +- CHNG/ENTER 2 </div>
<p>Finally, press the ENTER key to make the change. For example, as shown here the MCS-8 network address has been changed from 1 to 2:</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> NETWORK ADDRESS CHANGE MADE 2 </div>

Appendix D

Analog Sensor Input Reference Table

To troubleshoot analog sensor input problems and determine where the problem is, simply remove the sensor input connector block of the input you want to test and plug in a MCS-SENSOR-TEST block. If you do not have a MCS-SENSOR-TEST block you can connect a 100K ohm 1% ¼ watt resistor between the +5 and S1 pins of the suspect sensor input on the board with the original sensor connector block removed.

After you have done this, compare the reading displayed by the MCS-8 with the table of the most common sensor types on the right. If the reading is close to what is found in the table for that particular sensor type you can safely assume that the board is functioning normally and that the problem lies with the sensor itself or the wiring from the sensor to the board.

Sensor Type	Reading
CT100	57.0A
CT250	143.0A
CT500	287.0A
HUMD	54.0%
T100	77.0F
Ti150A	75.0P
Ti200	100.0P
Ti500	250.0P
Ti667A	334.0P

Appendix E

MCS-UPC Status LED Code Descriptions

Run LED	Error LED	Condition
2 flashes per second	Off	Normal
2 flashes per second	2 flashes alternating	Five minute auto-restart delay after system error
2 flashes per second	2 flashes in sync, then pause	Module is configured for a different baud rate than the rest of the network segment
2 flashes per second	3 flashes, then off	Module has just been formatted
2 flashes per second	4 flashes, then pause	Two or more devices on this network have the same ARC156 network segment address
2 flashes per second	On	Exec halted after frequent system errors or control programs halted
5 flashes per second	On	Exec start-up aborted, Boot is running
5 flashes per second	Off	Firmware transfer in progress, Boot is running
7 flashes per second	7 flashes per second, alternating	Ten second recovery period after brownout
14 flashes per second	14 flashes per second, alternating	Brownout

Appendix F

Resolving MCS-8, I/O and RO8 Snubber Network Leakage Issues

Each relay output on a MCS-8, I/O and RO8 board is protected by the use of on-board snubber networks. These networks consist of a resistor and capacitor in series connected from the common side of each relay to the normally open and normally closed sides. Its purpose is to suppress or “snub” the electrical arc that is produced when relay contacts open and close. Electrical arcs can shorten the useful life of a relay and can also cause the electronics on the controller board to malfunction.

In some cases the use of these snubber networks can cause an outbound device, such as a relay, to stay on even when the controlling relay on the MCS-8, I/O or RO8 board is turned off. This can occur in situations where the outbound device requires very little ac current to keep it on once it is energized. Because snubber networks normally pass a small amount of current when the circuit it is protecting is switched off, enough current may pass through these networks to keep the outbound relay on, even though the controlling relay is turned off.

An easy solution to this problem is to rewire the relay output as shown in the diagram to the right. As you can see, wiring the circuit in this way causes the outbound device to have the same voltage potential on both sides when it is not energized.

