


# MCS-SAIR

## Temp Sensor-Duct Mount Wiring Diagram

### Sensor Input

Set **DIGITAL/ANALOG**  
Jumper to Analog  
position.



5580 Enterprise Pkwy, Fort Myers, FL 33905 USA  
Phone: (239) 694 0089 - Fax: (239) 694 0031  
www.mcscontrols.com - support@mcscontrols.com

MCS-SAIR Wiring Diagram (2020-10-26).dwg

**MICRO**  
**CONTROL**  
**SYSTEMS**