



SOFTWARE RELEASE NOTES

MCS-CONNECT
Version 18.02.07
8/16/2016

Updates from previous versions:

New Features:

1. New sensor types and alarm types to support Danfoss VFD code.
2. Added fields to V17 structures to match changes in Firmware.
3. Added a new field to SW status Ram to be used in determination of type of board we are connecting to. Not currently used.
4. Began coding for the "View Only" version of MCS-Connect - INCOMPLETE

Bug Fixes:

1. Auth Keypad Popup not showing on new installs. Resolution: Changed the default value of the Auth Keypad Shown to TRUE to ensure that all new installations will start with the keypad shown.
2. In the EXV grid the default renderer is not allowing for row highlighting. Resolution: Removed the call to set the renderer.
3. Graphics Alarm Popup Issue. Resolution: Added a flag to check if the popup was already visible and only refreshed the table if it is instead of creating a new popup every time.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2016. Copying or distributing this document is prohibited unless expressly approved by MCS.