

Revision History

Date	Author	Revision	Description	
10-05-15	DEW	Rev. 1	Create APP]

MCS I/O PROTECT CONNECTOR R-MCS-R08 BOARD

Any questions regarding this release, contact: <u>support@mcscontrols.com</u>

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905 (239)694-0089 FAX: (239)694-0031 <u>www.mcscontrols.com</u>

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2015. Copying or distributing this document is prohibited unless expressly approved by MCS.

1.1. Installing MCS-I/O PROTECT CONNECTOR on MCS-R-MCS-R08-M BOARD

- 1. Unpack supplied new connector.
- 2. Stop power to MCS-R-MCS-M board.
- 3. Remove old connector from pins on board as shown in photo below.
- 4. Insert new 'New MCS-I/O-Protect connector on pins on board as shown.
- 5. Place OLD CONNECTOR IN PLACE on pins.
- 6. Reconnect I/O communication



