


APPLICATION NOTE

APP #154 HANBELL RC2 SERIES Oil Pin



Part #	Description	O-Ring	Compressor Model
3101-1169A	18mm Stop Pin	4201-VA119	RC2-170, RC2-200~580, RC2-620
3107-1169A	24mm Stop Pin	4201-VA122	RC2-610, RC2-710~RC2-930
4304-105	Connector - 1/2"NPT x 5/8"Flare		

The oil will be directed out of the compressor through the oil in and out connection by inserting the pin into the circulation line.

To complete this, follow these instructions:

- 1. Remove the plug.
- 2. Insert the pin for the compressor model as shown above.
- 3. Replace the O-Ring for compressor model as shown above.
- 4. Reinsert the plug.
- 5. Tighten the plug.

Any questions regarding this release, contact: support@mcscontrols.com