


# MCS-SAIR

## Temp Sensor-Duct Mount Wiring Diagram

### Sensor Input

Shield DRAIN WIRE must be connected to SENSOR "GND" Terminal.

Set DIGITAL/ANALOG Jumper to Analog position.



5580 Enterprise Pkwy, Fort Myers, FL 33905 USA  
Phone: (239) 694 0089 - Fax: (239) 694 0031  
www.mcscontrols.com - support@mcscontrols.com

MCS-SAIR Wiring Diagram (2012-11-09).dwg

