


MCS-STATIC-5"-B, 0.2"-B

Differential Pressure Transducer

Wiring Diagram




5580 Enterprise Pkwy, Fort Myers, FL 33905 USA
Phone: (239) 694 0089 - Fax: (239) 694 0031
www.mcscontrols.com - support@mcscontrols.com
MCS-STATIC-5-B, 0.2-B Wiring Diagram (2021-01-15).dwg



MCS-STATIC-5"-B, 0.2"-B

Differential Pressure Transducer

Wiring Diagram




5580 Enterprise Pkwy, Fort Myers, FL 33905 USA
Phone: (239) 694 0089 - Fax: (239) 694 0031
www.mcscontrols.com - support@mcscontrols.com
MCS-STATIC-5-B, 0.2-B Wiring Diagram (2021-01-15).dwg



MCS-STATIC-5"-B, 0.2"-B

Differential Pressure Transducer

Wiring Diagram



5580 Enterprise Pkwy, Fort Myers, FL 33905 USA
Phone: (239) 694 0089 - Fax: (239) 694 0031
www.mcscontrols.com - support@mcscontrols.com
MCS-STATIC-5-B, 0.2-B Wiring Diagram (2021-01-15).dwg

