


MCS-ZONE-II-OVR-T/R

Temperature Sensor

Wiring Diagram



5580 Enterprise Pkwy, Fort Myers, FL 33905 USA
Phone: (239) 694 0089 - Fax: (239) 694 0031
www.mcsccontrols.com - support@mcsccontrols.com

