



SOFTWARE RELEASE NOTES

MCS-CONFIG Version 14.00K 07/18/2013

Updates from previous versions:

New Features:

1. In HVAC config types V14 on the General Info tab under the Unit Indicators section adding a new RO drop down list called Unit Status Relay.

Bug Fixes:

1. In LWC config types V11 and V14 on the SI Info Screen under the type column when the type is a User Logic and the wizard loads if the Operand #1 or #2 type is a Loop# if the drop down list below it is set to Stage Steps t/o and the OK button is clicked when the wizard is loaded again the drop down list index reverts to Stage Steps w/o every time. Resolution: Replaced the text w/o with t/o in the LoopControlArray for index #45.
2. In ALL config types V11 and V14 when the user logs in as an Admin or Factory user and tries to modify the Auth Screen codes the code number reverts back to 0000. Resolution: The after column update function was testing each of the auth columns for the correct auth code entered for an Admin or Factory user instead of an Admin and Factory user therefore skipping the memory assignment when either one was false.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2013. Copying or distributing this document is prohibited unless expressly approved by MCS.