



SOFTWARE RELEASE NOTES

MCS-CONFIG Version 14.00M 08/02/2013

Updates from previous versions:

New Features:

1. In ALL config types that support BMS Points on the BMS Points screen under the Alarms section if the option on the Setup screen BACnet MV Values Start At: One is selected then on the Alarms screen there will be two new grids displayed called Alarm Types and Alarm Points with new points to display. If the option is set to 0 then the same grid with Fixed, Setpoints, and Alarms will be displayed.

Bug Fixes:

1. In ALL config types V11, V12, and V14 on the SI Info screen under the Display Type column when the type is a BMS_SI and it has already been set up in the BMS_SI popup with values if the Cancel button is clicked then all values in the popup are reset to default. Resolution: Test all fields in the popup when the Cancel Button is clicked and if they are all default then allow the current code to execute, otherwise if one of the fields is different then just leave all memory locations as is.
2. In LWC config types V14 on the BMS Points screen under the Loop States section on the two tables that show the Unit Control Info for the Magnum and the BMS-Gateway the text that is shown for the Pump/Fan Loop # States(Chart C) is incorrect. If the memory location is set for pumps then it should just say Pump or vice versa for Fans. Resolution: Adding a test that will see if it is set to Pumps or Fans and print out that text accordingly.
3. In ALL config types V11 and V14 on the Setup screen when the user enters a Factory or Admin Auth code and opens the Setup screen the Factory Startup and Run Hour Lockout panels are disabled. Resolution: Need to change the test that looks at the Auth Level from an Or to an And.
4. In ALL config types V11, V12, and V14 on the Auth screen if the user is Authorized at Factory Level and there are any rows in the Auth grid that are Admin Level then the row is blacked out and the user should not be able to modify the values behind the blacked out row. The Code column is allowing editing even when the row is blacked out. Resolution: Added a test to the else clause that says the user is either Admin or Factory to test the rows actual auth level and if the auth level is Factory but the row auth level is Admin then don't allow the change.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2013. Copying or distributing this document is prohibited unless expressly approved by MCS.

5. In ALL config types V14 on the System screen when the user clicks the Save Logo as Bitmap File MCS-Config pops up an error number 424: Object Required. Resolution: The Common Dialog box was named wrong.
6. In ALL config types V14 on the System screen when the user clicks the Load Bitmap button another System form is loaded behind the current form which causes an error when tried to close. Resolution: Add in a test that checks the config version for V14.
7. In ALL config types all versions on the schedule screen when the screen is loaded while MCS-Config is at MAX screen size there is an error number 380 thrown which crashes the program. Resolution: In the resizing of the window the .SmallChange property of the Vertical Scroll Bar was being assigned a value that was too large.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2013. Copying or distributing this document is prohibited unless expressly approved by MCS.