



SOFTWARE RELEASE NOTES

MCS-CONFIG Version 14.00X 11/25/2013

Updates from previous versions:

New Features:

- 1. In ALL config types V14 on the Main Info screen when the main menu bar loads the UL Points button is made visible and clickable. When clicked this screen shows the State charts starting at 0 no matter what the BACnet MV Values Start At option is set to on the Setup screen. Removing this button and modifying the current state charts on the BMS Points screen to have three columns now. There will be a MCS/Modbus column, BACnet column, and the State Text column. The only column that will change is the BACnet column depending on what the setting is for BACnet MV Values Start At: on the Setup screen.**
- 2. In MicroMag-AAON config types adding new SI names Hw EntTemp, Hw EntHumd, Temp 1, Temp 2, Temp 3, Temp 4 to the SI Names Array.**
- 3. In ALL MicroMag config types on the Setpoint Info screen adding a new Setpoint Type called Warning to the Type of Setpoint column drop down selection list. This new type will work exactly as the Alarm type.**

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2013. Copying or distributing this document is prohibited unless expressly approved by MCS.