



SOFTWARE RELEASE NOTES

MCS-CONFIG Version 17.00G 12/10/2014

Updates from previous versions:

New Features:

1. In CENT config types V17 on the Circuit SI screen on the second grid adding a new column after the Vane Position column called Vane Control Method that will hold two different text values Vane% SI and FLA%. If the Vane Position column is set to Not Used then the compressor is locked to use the FLA% as the Vane Control Method, if the Vane Position column is set to an SI then the Vane Control Method is set to run off of the Vane% SI.
2. In ALL MicroMag config types adding 12 new RO names to the Chiller RO name array list. COMP 1 C, COMP 2 C, COMP 1 D, COMP 2 D, UNLOADER 1 A, UNLOADER 2 A, UNLOADER 3 A, UNLOADER 1 B, UNLOADER 2 B, UNLOADER 3 B, UNLOADER 1 C, UNLOADER 2 C, UNLOADER 3 C, UNLOADER 1 D, UNLOADER 2 D, UNLOADER 3 D.

Bug Fixes:

1. In RTU config types V14 and V17 on the MAG RTU screen under the Heating Info section on the Primary Panel changing the caption for Ignition Indicator to Ignition Indicator(DI Only).
2. In CENT config types V14 and V17 on the MAG CENT screen under the Compressor Info section hiding the Vane Control Method panel.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2014. Copying or distributing this document is prohibited unless expressly approved by MCS.