



SOFTWARE RELEASE NOTES

MCS-CONFIG Version 17.00Q 03/20/2015

Updates from previous versions:

New Features:

1. In HVAC config types V17 on the MAG HVAC screen under the CPM Info section adding a text field that will hold a 0-255 range of value called Valve Open Time (0-255 seconds).
2. In CPM config types V17 on the CPM INFO screen under the Pump Info section on the Pump Group grid adding a new column called Min Valves Per Pump will be placed in the grid in between Max Pumps Per Chiller and Water Out Temperature. The column will hold a drop down list box from 0-10. If the memory location is less than 0 or more than 10 then the location will be set to 0.

Bug Fixes:

1. In ALL config types V14 and V17 Setup screen print, the NO KEYPAD/DISPLAY feature is not printing out. Resolution: Add the test for the correct index for NO KEYPAD/DISPLAY.
2. In ALL config types ALL versions the orientation of the print output is not the same as the orientation on MCS-Config screen when printing a full report. Resolution: Move the different print functions in the same order as MCS-Config.
3. In ALL MicroMag config types V12 on the Circuit Base first grid under the Total # of Comp Stages column the word Stages is cutoff by the column header border. Resolution: Change the columns width property so the words wrap better inside the column header.
4. In ALL MicroMag config types V12 on the Circuit Base first grid under the Comp Type column changing two names at the bottom of the drop down list from Multi-Stage Scroll and Multi-Stage Scroll w/Unloaders to Multi-Stage Comp w/Loaders and Multi-Stage Comp w/Unloaders.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2015. Copying or distributing this document is prohibited unless expressly approved by MCS.

5. In ALL config types V17 on the Setup screen in the Ethernet Communication panel the tab order of the IP Address is not working correctly and when a bad value is entered a popup message is displayed.
Resolution: Setting the tab order to move to each box in the correct order. Commenting out the popup message box source code.
6. In ALL config types V17 on the System screen the Software Version should say Firmware Version.
Resolution: Change the text value property to Firmware Version.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2015. Copying or distributing this document is prohibited unless expressly approved by MCS.