



SOFTWARE RELEASE NOTES

MCS-CONFIG Version 17.01A 11/20/2015

Updates from previous versions:

New Features:

1. In ALL config types V17 where the Circuit Base screen is used under the HGB column changing one of the selections from Modulate to MOD. AO & RO and adding two new selections MOD> AO and MOD. ROs.

Bug Fixes:

1. In ALL config types V17 Setpoint Info grid Night Setback column needs to be changed. Resolution: Change the column caption to Setback.
2. In ALL config types V14 & V17 SI Info grid Change three column headings along with the popup to enable/disable. a.)Change the text on the SI info grid for the Sensor Fault columns from Sensor Fault Low to Select Faults Sensor Type Low and Sensor Fault High to Select Faults Sensor Type High. b.)Change the text on the SI info grid in config for the Enable/DisableSensor Faults columns to Custom/Defaults (Click Here For All). c.)On the popup that displays when the column header is clicked changing the text from Click to ENABLE all low/high sensor faults and use custom values saved in the config to Click to set custom types for all sensors and use custom values saved in the config d.)On the popup that displays when the column header is clickedchanging the text from Click to DISABLE all low/high sensor faults to theirdefault values of -999(low) and 9999(high) to Click to set all low/high sensorsto their default values of -999(low) and 9999(high)

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2016. Copying or distributing this document is prohibited unless expressly approved by MCS.