



RELEASE NOTES

MCS-CONFIG Version 9.03EE 10/19/2012

Updates from previous versions:

New Features:

1. In HVAC, CENT, and RTU config types adding a new condenser type to the Condenser Type drop down list on the Condenser Info screen. The new type will be called Modulating Step Common. The same points that are displayed for an RO Step Common will be displayed for the new type except for AO Starting Stage. Also, with this change setting # of Cond Stages to 0 if the Starting Condenser RO is "Not Used".
2. In RTU config types on the MAG RTU info screen under the general section changing Ventilation Mode to Fan Only Mode and adding a new panel with a caption that reads: Setpoint Override Sensors. On this panel there will be seven SI drop downs:
 - a. Moving Target(SP#1) Reset and renaming-Cooling Target
 - b. Cooling Enable
 - c. Heat Target
 - d. Heat Enable
 - e. Reheat Target
 - f. Dehumid Target
 - g. Dehumid Enable

Bug Fixes:

1. Changing the amount of decimal places from 1 to 0 for sensor types SUP TMP TRG and SUP FLW TRG.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2012. Copying or distributing this document is prohibited unless expressly approved by MCS.