



RELEASE NOTES

MCS-CONFIG Version 9.03Z 09/17/2012

Updates from previous versions:

Bug Fixes:

1. In all config types that use the ROV11 info grid when the user sets up the compressor ROs and tries to set a value in the VFD Start % or VFD Start % Time if the compressor RO that is being set has the last AO selected for its Compr Speed(%) AO on the Circuit Base screen second grid fourth column then the values entered will be set to null. Resolution: Set the Number of AOs to the max limit.
2. In all config types on the BMS Points info screen under the Compressor Points section on the MCS Circuit State Chart adding 5 missing states to the grid.
3. In RTU config types on the RTU MAG Info screen under the general section changing the caption for the panels that hold the Ambient SIs from Ambient Temp and Ambient Humidity to Outside Temp and Outside Humidity.
4. In RTU config types on the RTU MAG Info screen under the heating section when the user selects Direct Fire as the heat type changing the caption of all MOD Gas drop downs to read Direct Fire. Then back to MOD Gas when the heat type is MOD Gas.

Any questions regarding this release, contact:
support@mcscontrols.com

Micro Control Systems, Inc. 5580 Enterprise Parkway Fort Myers, Florida 33905
(239)694-0089 FAX: (239)694-0031 www.mcscontrols.com

Information contained in this document has been prepared by Micro Control Systems, Inc. and is copyright © protected 2012. Copying or distributing this document is prohibited unless expressly approved by MCS.