Micro Control Systems APPLICATION NOTE APP-031

Demo Reciprocating/Screw Panel Swap Instruction Sheet

Revision History

Date	Author	Description	
10/18/01	K Mitchell	Created document	

Panel Swap Instructions

- 1. Turn off and unplug power and communication cables.
- 2. Remove ribbon cable attaching top panel and bottom panel.
- 3. Remove top panel by unscrewing four Philips head screws.
- 4. Remove bottom panel by unscrewing seven Philips head screws.
- 5. Change software chip on MCS-8 at location U11 on bottom panel.
- 6. Install bottom panel (7 screws).
- 7. Install new top panel (4 screws).
- 8. Connect ribbon cable attaching top and bottom panels.
- 9. Plug in cables 120/240 AC and communication.
- 10. Download correct CFG (BRIEFRA.CFG (recip) or BRIEFSA.CFG (screw).